XR TIME SYNCHORNIZATION

14000 SERIES SATELLITE TRANSMITTER

INSTALLATION & USER GUIDE

Doc Part No.: 14000M 08.12.14

Legal Notice

Copyright ©2014 Primex Wireless, Inc. All rights reserved.

U.S. Patents 6,873,573; 7,352,657. Other Patents Pending.

Printed in the USA.

Information in this document is subject to change without notice. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical or otherwise, for any purpose, without the prior written permission of Primex Wireless.

Contact Primex Wireless

	United States	Canada	United Kingdom
Address	965 Wells Street Lake Geneva WI 53147	1310 Kerrisdale Blvd. Unit #4 Newmarket, ON L3Y 8V6	Unit G420 Dean Clough Halifax, West Yorkshire HX3 5AX
Email	info@primexinc.com	info@primexwireless.ca	info@primexwireless.co.uk
Web	www.primexwireless.com	www.primexwireless.ca	primexwireless.co.uk
Telephone	(800) 537-0464	(800) 330-1459	0800-3896996
Fax	(262) 248-0061	(905) 952-0134	01422-349462

CONTENTS

Important Safety Instructions **4**

Regulatory Compliance **5**

14000 Satellite Transmitter Specifications **6**

14000 Series Transmitter Specifications 6

Transmitter Display Specifications - 14000 Series 6

Receiver Switch Specifications 7

Configure and Install 14000 Satellite Transmitter **8**

Verify Setup of Primary Transmitter with GPS Receiver 8

Satellite Transmitter Location Guidelines 8

Establish Connections - 14000 Transmitter Internal Antenna 9

Setup Receiver Switch 9

Install Receiver Switch 10

Confirm Reception with Transmitter 12

Verify Last Time Update 12

Special Circumstances - DST Time not Observed 12

Setup Multiple Transmitters Within the Same Facility 13

Support **14**

Warranty **15**

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE INSTALLATION, OPERATION, OR MAINTENANCE OF PRODUCT.

Some of the following information may not apply to your particular product model; however, as with any electronic product, precautions should be observed during installation, operation, and maintenance.

- Never operate the transmitter without the antenna being properly connected to the transmitter. Operating the transmitter without an antenna can lead to permanent damage of the transmitter and poses a safety risk.
- Do not touch any of the antennas while broadcasting.
- Standard acceptance procedures must be followed prior to operating this equipment in the proximity of life support systems.
- Do not operate the transmitter outdoors, in wet areas were there is standing water, or in areas where there is condensation or the risk of condensation. Use in any of these environments will damage the transmitter and void the warranty.
- Do not open the transmitter to alter the internal elements in any way. This will void the warranty and could lead to unsafe conditions, malfunction, and violations of FCC/IC regulations.

Primex Wireless disclaims any liability or responsibility for the results of improper or unsafe installation practices.

REGULATORY COMPLIANCE

Federal Communications Commission (FCC) / Industry Canada (IC)

License Requirements

- Operation of the Transmitter requires a FCC/IC operating license, which must be obtained prior to operation.
- FCC licenses must be renewed every 10 years and the IC licenses must be renewed annually.
- As a service, Primex Wireless will file the license application if the end-user desires it. An end-user that does not want Primex Wireless to file for the original site license will be required to complete a waiver form, file the required application, and receive a valid license from the FCC/IC prior to use. If you have any questions or need any assistance, please contact Primex Wireless Technical Support.
- Primex Wireless requires a copy of the licenses in order to complete the factory presets.

Product Compliance

- This device complies with Part 90 and Part 15 of the FCC rules and RSS-210 of Industry Canada.
- Operation of this device is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference, including interference that may cause undesired operation.

Changes or modifications to any part of the Primex Wireless System components not expressly approved by Primex Wireless could void the user's FCC/IC authority to operate the equipment.

Radio Frequency (RF) Exposure

14000 Satellite Transmitter Specifications

14000 Series Transmitter Specifications

- 1 Watt maximum transmission (at transmitter)
- 72MHz frequency range
- 16 channels available (pre-programmed prior to shipping)
- Daylight Saving Time bypass switch
- Time zone adjustment switch (pre-programmed on 14000-E prior to shipping)
- LCD display for time, date, and signal verification
- Dimensions: 16.0"L x 12.0"W x 1.9"D (40.6 cm x 30.5 cm x 4.8 cm)
- Power Supply:
  - Input: 120 VAC, 50/60 Hz, 0.4 Amp
  - Output: 9 VDC, 2.0 Amp
  - 6' (1.83 m) cord
- Operating Range: 32°- 158°F (0° - 70°C)

Transmitter Display Specifications - 14000 Series

The transmitter has a lighted front display that shows important information.

Figure 1: 14000 Series Transmitter Display



Display Specifications

Table 1: 14000 Transmitter Display Specifications

Component	Description
Time	Displays the precise time received from the GPS Receiver. If AM or PM is on the display, then the 12-hour option is selected. If neither AM nor PM is on the display, then the 24-hour option is selected.
Daylight Saving Time	The letters "DT" (Daylight Saving Time) or "ST" (Standard Time) will be displayed when adjustment for Daylight Saving Time is active. If neither "DT" nor "ST" is displayed, then switch #3 is in the down position and the transmitter will not adjust for Daylight Saving Time.
GPS Communication	The GPS Communication indicator appears when the transmitter is communicating with the GPS Receiver. The parentheses indicate the time signal is being received.
Day/Date	Displays the day and date received from the GPS satellite.
Channel Number	Displays the channel number (1-16) the transmitter is set to.
Red LED	The red LED (Light Emitting Diode) is located on the right side of the front panel of the transmitter. The LED flashes on initial setup until a GPS time signal is received or when a severe GPS Receiver signal problem has occurred and no time data has been received from the GPS Receiver in 48 hours. See the Troubleshooting section of this guide for additional information.

Receiver Switch Specifications

Included with Satellite Transmitter.

Table 2: Receiver Switch Specifications

Component	Description
Cable	5' (1.52 m) RS232 cable connects Receiver Switch to the Satellite Transmitter
Dimensions	5.75" (14.6 cm) L x 4.25" (10.8 cm) H x 1.25" (3.16 cm) D
Antenna	12.5" (31.75 cm) L
Weight	0.75 lb (.34 kg)
Power Supply	Input: 120 VAC, 50/60 Hz, 0.4 Amp Output: 9 VDC, 0.25 Amp, 6' (1.83 m) cord
Operating Range	-32° - 158° F (-36° - 70° C)

CONFIGURE AND INSTALL 14000 SATELLITE TRANSMITTER

Verify Setup of Primary Transmitter with GPS Receiver

Installation of the Satellite Transmitter begins with setup of the primary transmitter with a GPS receiver.

- The primary transmitter must be setup and working prior to installation of the Satellite Transmitter.
- The primary transmitter transmits the signal to the Satellite Transmitter via the Receiver Switch.

> **NOTE:** For the setup and installation of the primary transmitter, refer to the installation guide of the primary transmitter model.

Satellite Transmitter Location Guidelines

The Satellite Transmitter must be in a location where it can receive a signal from the Primary Transmitter.

Typical Application Drawings

> **CAUTION:** Do not adjust the channel numbers on your transmitter. This figure is an example designed to demonstrate how a repeater switch chain works.

Figure 2: Example of Horizontal Installation



Figure 3: Example of Vertical Installation



Establish Connections - 14000 Transmitter Internal Antenna

1. Plug the supplied 9 Volt 2.0 Amp DC power supply (transformer) into the transmitter.
2. Plug the power supply (transformer) into a 120 VAC outlet.

Setup Receiver Switch

To access the Receiver Switch menu preferences, press the **Menu** button located on the front of the unit. By pressing and holding the Menu button the Receiver Switch will cycle through the menu options.

- While in the Channel menu option, if there are no changes made in a minute of entering a menu section, it will time out and save the displayed value, exiting the menu mode.
- If a value is changed while cycling through the menu, it will be saved and continue to cycle.
- While in test mode, it will remain in the selected mode until the menu button is pressed again to exit.

After entering changes, it is recommended to step through the menu options until the option donE is displayed to exit the menu mode; the menu will display donE.

> **NOTE:** Changes made in the Menu will be saved when the menu is exited.

Table 3: Menu Mode Options Specifications

Display	Menu	Description
Ch	Channel	The Channel Number menu allows the user to change the channel by using the up or down button. The channel number must be set to the same channel number as the Primary Transmitter or other Satellite Transmitter broadcast channel.
tESt	Test	The Test menu allows the user to hear audible beeps with a valid time/date reception. This will occur 5 seconds after the test menu is selected. It will continue to be in this mode until the menu button is pressed again, leaving the menu mode and returning to normal mode.
LtU	Last Time Update	The Last Time Update menu allows the user to see the last time update, time and date (cycles every second). This will occur 5 seconds after last time update menu is selected. The unit will remain in this mode for a minute, wherein it will time out and return to the menu mode.
Soft	Software Revision:	The Software Revision menu allows the user to see the software revision on the unit. This will occur 5 seconds after last time update menu is selected. The unit will remain in this mode for a minute, wherein it will time out and return to the menu mode.
dst	Daylight Saving Time Calendar	The Daylight Saving Time Calendar menu allows the user to see the current Daylight Saving Time calender in use. This will occur 5 seconds after last time update menu is selected. The unit will remain in this mode for a minute, wherein it will time out and return to the menu mode.
donE	Done	The Done menu allows the user to exit the menu mode. This will occur 5 seconds after the done menu is selected returning to the normal mode saving all settings.

Install Receiver Switch

1. Attach the rubber antenna to the Receiver Switch, as shown Figure 4

Figure 4: Receiver Switch



2. Power down the Satellite Transmitter.
3. Connect the serial cable of the Receiver Switch into the GPS IN Socket on the back of the Satellite Transmitter.

Figure 5: Satellite Transmitter - Back View



4. Power up the Satellite Transmitter.
5. Press the **Menu** (middle button) on the front of the unit to scroll through the Menu options to the **Channel Mode** (Ch displayed)
6. Press the up or down button to set the channel number to match the primary transmitter transmit channel.
7. Scroll through the menu to the **donE** mode. After 5 seconds the Receiver Switch will time-out and return to the Day/Date mode saving the channel selection.
8. Determine the best mounting location for the Receiver Switch.
   a. Locate the room/area the transmitter is to be installed in. Close all doors and windows before testing.
   b. DO NOT hold the rubber antenna during testing, as this can affect the sensitivity of the receiver. Instead, hold the switch by the sides of the housing while locating the best mounting position.
   c. Place the Receiver Switch in the EXACT location where it will be mounted. This is crucial as closeness to walls can degrade receiver sensitivity. If the exact location is not known, be sure to test the Receiver Switch in several locations. If any locations tested are unsuccessful, note this for future reference.
9. Power Cycle the Receiver Switch power at least 1-2 times after installation is complete and verify the green LED begins to flash. Doing this will ensure a solid signal is being received.
   - To cycle power the Receiver Switch, remove the switch cover by removing the two phillip head screws, located in the upper right and lower right of the unit. Use caution when removing the cover to avoid causing the up or down menu buttons to fall off the circuit board.
   - Press and release the **Reset** button, located in the upper right corner to the left of the antenna mounting, 1 to 2 times and verify the green LED begins to flash. The flashing of the green LED indicates a solid signal is being received.
10. Mount the Receiver Switch in its final location and verify the switch settings. For additional information, see "Setup Receiver Switch" located on page 9.

> **NOTE:** When the Receiver Switch is mounted, its antenna must be vertical. Do not use an analog clock to determine if a mounting location will be adequate for signal reception. The receiver in a clock is more sensitive than the Receiver Switch and therefore the switch may not work in areas where a clock works.

Confirm Reception with Transmitter

When the Receiver Switch is connected to the powered Satellite Transmitter, an **R** will appear in the upper right corner of the transmitter's front panel LCD display window. This may take up to a minute. The green RX LED on the Wireless Receiver Switch will flash when a valid signal is initially received. This LED will then flash once per second, signifying a successful time update. If the green LED is solid, the Receiver Switch missed the last update. Time updates occur once per hour.

> **NOTE:** If the Satellite Transmitter does not receive a time update from the Receiver Switch after 48 hours, its yellow "Caution" LED will begin flashing and an error will be logged.

Verify Last Time Update

To verify the last time the Receiver Switch received and applied a valid time/date update, toggle through the receiver switch Menu to the Last Time Update (LTU) section.

Special Circumstances - DST Time not Observed

For geographic areas that do not observe Daylight Savings Time (DST) set the transmitter's Daylight Saving Bypass reciver switch bypass step below.

> **NOTE:** In the event the receiver switch does not receive a transmitter signal when the DST change is scheduled to occur, the switch will automatically adjust the time on the transmitter. In areas that do not observe DST this feature must be disabled on the circuit board of the switch.

1. Disconnect the receiver switch from the Satellite Transmitter.
2. On the Receiver Switch remove the access cover and change dip switch #5 to the "ON" position, as shown in Figure 6

Figure 6: Receiver Switch with Cover Removed



Setup Multiple Transmitters Within the Same Facility

1. Setup and install each Satellite Transmitter and Receiver Switch.
2. The channel number of the Satellite Transmitter is preset to the channel number specified on the red label located on the top of the box the transmitter was packaged in. Contact Primex Wireless Technical Support if you require assistance.
3. Use the buttons on the Receiver Switch to toggle through to LED menu, and set the channel number to match the XR system channel with the strongest available signal. This signal may be from either the Primary Transmitter or the nearest Satellite Transmitter.
4. Cycle power on the Receiver Switch after changing the channel.
    - To cycle power the Receiver Switch, remove the switch cover by removing the two phillip head screws, located in the upper right and lower right of the unit. Use caution when removing the cover to avoid causing the up or down menu buttons to fall off the circuit board.
    - Press and release the **Reset** button, located in the upper right corner to the left of the antenna mounting, 1 to 2 times and verify the green LED begins to flash. The flashing of the green LED indicates a solid signal is being received.

SUPPORT

Technical Support

Prime Wireless Technical Support responds to specific questions about product features, system configuration, and troubleshooting. All support services will be delivered in accordance with your organization's support agreement and warranties.

Contact Technical Support

Before contacting Primex Wireless Technical Support, make sure you have satisfied the system requirements that are listed in your product documentation.

When you contact Technical Support, please have the following information available:

- Customer ID
- Problem description
- Device hardware information
- Error messages
- Troubleshooting performed before contacting Primex Wireless
- Recent network changes (SNS products only)

Technical Support	
Telephone	(800) 404-8112
Email	techsupport@primexinc.com
Fax	(262) 248-0061
Hours	7:00 am to 7:00 pm CST | Monday through Friday
Web	www.primexwireless.com

WARRANTY

One Year Limited Warranty

Primex Corporation warrants this product to be free from defects in materials and workmanship for a standard of one year from the date of purchase. Primex will at its sole option, repair or replace any components that fail in normal use. Such repairs or replacements will be made at no charge to the customer for replacement parts. The customer will be responsible for any transportation costs. This warranty does not cover failures due to misuse, abuse, accidental or unauthorized alterations or repairs.

The warranties and remedies contained herein are exclusive and in lieu of all other warranties express or implied or statutory, including any liability arising under any warranty or merchantability or fitness for a particular purpose, implied, statutory or otherwise. In no event shall Primex be liable for any incidental, special, indirect or consequential damages, whether resulting from the use, misuse or inability to use this product or from defects in the product. Some states do not allow this exclusion or limitation of incidental or consequential damages so the above limitations or exclusion may not apply to you.

To obtain warranty service: If after following the instructions in the product guide, you are certain the product is defective, please contact Primex Wireless Technical Support to assist with troubleshooting the issue. If the issue cannot successfully be resolved and the product is under warranty, an RMA (Return Material Authorization) will be generated. The RMA form will be provided via email with detailed instructions for the return. All merchandise returned must be shipped to Primex Wireless, Attn: Returns Dept., N3211 County Road H, Lake Geneva, WI 53147.

Primex Wireless retains the exclusive right to repair or replace the unit at its sole discretion. All merchandise returned must be shipped to Primex Wireless, Attn: Returns Dept., N3211 County Road H, Lake Geneva, WI 53147. Primex Wireless retains the exclusive right to repair or replace the unit at its sole discretion. Such shall be your sole exclusive remedy for any breach of warranty.